

# BTA Towbars

Australia's Towing Equipment Specialist



## Fitting Instructions: LDV03H

Vehicle: Deliver 9 LDV Van

Towing Capacity: 2800 / 280Kg

Fitting Kit: 2 – 10mm Flat washers

2 – Dee Shackles

**\*ECM REQUIRED.**

1.	Remove and discard crash support panel. See photo at bottom of page.
2.	Bumper cut required prior to fitment. Locate centre of bumper, Mark 40mm either side. Cut from edge of bumper up 100mm.
3.	Mount towbar using original bolts. Use 10mm flat washers as spacers for the forward most bolts on towbar bottom support plate (1 Either side)
4.	Fit 2 bumper holding plugs to supports. Tighten all bolts.
5.	Apply Towbar Rating Labels to driver's side door sill and non-removable part of the towbar.

